

Good Practice Guide

Glass and Dishwashing

UK

Getting The Best From Your Machine

DO

- ✓ **DO** allow the machine to heat for at least 45 minutes or until the green light is on.
- ✓ **DO** check detergent and rinse aid levels in bottles.
- ✓ **DO** pre-rinse all glasses, cutlery and crockery.
- ✓ **DO** ensure all filters are in position.
- ✓ **DO** allow machine to complete full wash cycle.
- ✓ **DO** ensure water softener (if fitted) is regenerated with salt regularly*.

DO NOT

- ✗ **DO NOT** switch the machine OFF whilst washing/rinsing.
- ✗ **DO NOT** open machine hood whilst washing/rinsing.
- ✗ **DO NOT** overload basket.
- ✗ **DO NOT** wash ash trays.

Keeping Your Machine Clean

DO

- ✓ **DO** change the wash water regularly.
- ✓ **DO** remove wash and rinse arms daily and clean.
- ✓ **DO** remove basket ramp daily and clean.
- ✓ **DO** remove all filters daily and clean.
- ✓ **DO** wash the chamber out daily.
- ✓ **DO** leave the hood open after cleaning.

DO NOT

- ✗ **DO NOT** use domestic detergents.
- ✗ **DO NOT** use cleaning agents that contain Chlorine, Bleach or Hypochlorite.
- ✗ **DO NOT** use steel wool, wire brushes or any other abrasive materials.
- ✗ **DO NOT** use a jet wash or hose pipe on the machine.

*Damage caused to the machine by limescale damage due to lack of water softener or incorrect regeneration of a softener is **NEVER** covered by the manufacturers warranty.

CLASSEQ